



ROJO FOX

**SPECIFICATION**

**EN**

**MODEL:** RJ10  
**BATTERY:** 21700 X 2  
**CAPACITY:** 10,000mAh  
**TYPE-C INPUT:** 5V3A;9V2A;12V1.5A; **18W**  
**TYPE-C OUTPUT:** 5V3A;9V2.22A;12V1.5A; **20W**  
**USB-A OUTPUT:** 5V4.5A;4.5V/5A;9V2A;12V1.5A; **22.5W**  
**MATERIAL:** ABS  
**SIZE:** 82.80x62x25mm  
**WEIGHT:** 178.5g

**QUICKSTART GUIDE**

**Charging external devices:**

- Turn on the power bank with the button or connect any device for automatic start-up.
- USB-A output: connect the charging cable (not included) to the USB-A port on the power bank and connect to the device. The power bank will automatically start the charging process and the LED display will show the remaining charge level of the power bank.
- Built-in USB-C output: connect the charging cable to the device. The power bank will automatically start the charging process and the LED display will show the remaining charge level of the power bank.
- When the fast charge function is activated, the LED display will show a green lightning symbol – . If the adapter or cable does not support the quick charge function, the display will only show the percentage of the power bank's charge level.
- After the connected device is fully charged, disconnect the USB cable. The LED screen will turn off after 30 seconds of inactivity.

**HOW TO CHARGE THE BATTERY**

**Charging the Power Bank:**

To charge the power bank battery, connect it to the USB port of a computer, mains charger or a compatible AC adapter using the USB cable.

- USB-C input: connect the charging cable with a USB connector (USB-C 3A cable included) to the USB-C port on the power bank and connect to a power source.
- Activation of the quick charge function will be signaled by the appearance of a green lightning symbol – .
- When fully charged, the LED display will show "100%", disconnect the USB cable. The power bank is ready for use. The LED display will turn off after 30 seconds of inactivity.

**PRECAUTIONS**

1. Charging time depends heavily on brand of adaptors being used due to different specifications.
2. Original Type-C cable is recommended to charge Type-C device.
3. An adaptor plug maybe required to use the original charging cable for the Galaxy Tab.
4. Do not expose product to fire or extremely high temperatures.
5. Optimum working temperature for device is lower 60°C.
6. Do not attempt to disassemble or modify the battery in order to avoid danger. Use the device with caution-avoid dropping or impact.

**CAUTION: If device is turned off due to improper use (circuit protected) and is unable to turn on, please recharge device battery or submit a support ticket. Please use Adapter, if the input voltage is higher.**

**SPESIFIKASI**

**ID**

**MODEL:** RJ10  
**BATERAI:** 21700 x 2  
**KAPASITAS:** 10,000mAh  
**TIPE-C INPUT:** 5V3A;9V2A;12V1.5A; **18W**  
**TIPE-C OUTPUT:** 5V3A;9V2.22A;12V1.5A; **20W**  
**USB-A OUTPUT:** 5V4.5A;4.5V/5A;9V2A;12V1.5A; **22.5W**  
**MATERIAL:** ABS  
**UKURAN:** 82.8x62x25mm  
**BERAT:** 178.5g

**PANDUAN QUICKSTART**

**Pengisian daya perangkat eksternal :**

- Turn on the power bank with the button or connect any device for automatic start-up.
- Output USB-A: sambungkan kabel pengisi daya (tidak termasuk dalam box) ke port USB-A pada power bank dan sambungkan ke perangkat. Powerbank akan secara otomatis memulai proses pengisian daya dan layar LED akan menunjukkan tingkat daya yang tersisa pada Powerbank.
- Output USB-C internal: sambungkan kabel pengisian daya ke perangkat. Powerbank akan secara otomatis memulai proses pengisian daya.proses pengisian daya dan layar LED akan menunjukkan tingkat daya Powerbank yang tersisa.
- Ketika fungsi pengisian daya cepat aktif, layar LED akan menampilkan simbol Petir berwarna hijau - . Jika adaptor atau kabel tidak mendukung fungsi pengisian daya cepat, layar hanya akan menampilkan persentase daya.
- Setelah perangkat yang tersambung terisi penuh, lepaskan kabel USB. Layar LED akan mati setelah 30 detik tidak ada aktivitas.

**Pengisian daya pada Powerbank :**

Untuk mengisi daya baterai Powerbank, sambungkan sumber daya listrik (adaptor AC atau komputer yang kompatibel dengan kabel USB) ke port input Type-C pada Powerbank.

- Input USB-C: sambungkan kabel pengisian daya dengan konektor USB (kabel USB-C 3A disertakan di dalam box) ke port USB-C pada power bank dan sambungkan ke sumber daya listrik.
- Aktivasi fungsi pengisian daya cepat akan ditandai dengan munculnya simbol kilat hijau - .
- Ketika daya Powerbank terisi penuh, layar LED akan menunjukkan "100%" , lepaskan kabel USB. Powerbank siap digunakan. Layar LED akan mati setelah 30 detik tidak ada aktivitas.

**PENTING**

1. Waktu pengisian daya sangat bergantung pada merek adaptor yang digunakan disebabkan spesifikasi yang berbeda.
2. Direkomendasikan untuk menggunakan kabel Tipe-C original untuk mengisi daya perangkat Tipe-C.
3. Adaptor mungkin diperlukan untuk menggunakan kabel pengisian daya asli untuk Galaxy Tab.
4. Jangan sampai produk terpapar api atau suhu yang sangat tinggi.
5. Suhu kerja optimal adalah lebih rendah 60°C.
6. Jangan membongkar atau menggerakkan baterai untuk menghindari bahaya. Gunakan perangkat dengan hati-hati-hindari terjatuh atau terbentur.

**CAUTION: Jika perangkat mati karena penggunaan yang tidak benar (perlindungan sirkuit), harap isi ulang baterai perangkat atau hubungi customer service kami. gunakan Adaptor, jika tegangan input lebih tinggi.**