



ROJO FOX

Portable Projector

K5



※User Manual※



Attention


Please read this manual carefully before use and keep it for future reference.

- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure Description

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.





Remote Component and Functions



Power
 Arrow Signalsource
 UP
 Left OK Right
 DOWN
 Menu Home Back
 Volume- Volume+
 Mouse


Power ON/OFF

Power On

Long press Power button on projector for 3 seconds.

Power Off

When the projector is power-on, press and hold the power button on the projector or the remote control for 3s to power off.




Focus Adjustment

When projector is on, adjust sharpness by focus wheel on the back of projector.




Launcher Ui




OSD Language

Setting - System Settings - OSD Lang > To choose your language.




Home Background

Setting - System Settings - Home Background > Choose the Home Background you want < Blue, Dark blue, White, Grey >.



Projector Mode

Setting - System Settings - Flip > To select different mode according to your application scenario. Four modes are available < Front Table, Front Ceiling, Back Table, Back Ceiling >.




Media Player

Insert the U disk and click the USB icon on the homepage to read the local video & music & photo & Book.



HDMI Signal

Connect projector and external sourcing device by HDMI cable. Enter HDMI on the homepage, the signal from the sourcing device will be transmitted to projector and cast out.



On-screen image

Ios system

1. Connect the projection device and the mobile phone to the same network.
2. Slide down the phone to open the control center and click the screen mirror button (slide up the iPhone6/7/8 series phone to open the control center).
3. Select the name of the device to be on the same screen and start on the same screen.




Android @ISO screen projection

1. Connect the projection device and the mobile phone to the same network.
2. Open the mobile APP playback interface and click the words "Show TV".
3. Select the device name to complete the screen projection.



timeset



【Safety instructions】

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations) ,etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating.
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

【Disclaimer】

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.